

Left and Right faucet hole locations for:
ST 5126
ST 5130
ST 6032

- 1- Using a measuring tape and a level, trace a horizontal line in the faucet deck at 1-3/4" from the inside tub with a light pencil that can be erased after faucet drilling.
 - 2- Mark center of faucet hole locations as indicated below and drill pilot holes.
 - 3- Drill 1-1/2" (38mm) holes in the faucet deck.
- NOTE: Before drilling make sure that bathtub metal frame is not interfering with the hole locations**

